

Architectural Window Film Installation Guide

Architectural Window Film Installation Guide

1. Preparation:

- Thoroughly clean the glass surface to remove dust and debris.
- Measure and cut the film to fit the window, leaving slight excess.

2. Application:

- Wet the window with a soap and water solution.
- Remove the protective liner and spray the adhesive side with the solution.
- Apply the film to the glass, starting from the top.
- Use a squeegee to remove excess water and air bubbles.
- Trim any overhanging edges.

3. Curing Time:

- Allow 48-72 hours for the film to fully adhere.
- Do not clean the film surface during this period.

4. Maintenance:

- Clean with non-abrasive solutions and a soft cloth.
- Avoid sharp objects that could scratch the film.

For best results, follow these steps carefully or contact a professional.