

# Automotive Window Film Installation Guide

## Automotive Window Film Installation Guide

### 1. Preparation:

- Clean the window thoroughly with a mild soap and water solution.
- Remove all dust, dirt, and debris.
- Measure and cut the film slightly larger than the window.

### 2. Application:

- Spray the window with a soap & water solution.
- Remove the protective backing from the film.
- Position the film on the window and align properly.
- Use a squeegee to remove air bubbles, working from the center outward.
- Trim excess film along the edges.
- Let the film cure for 48 hours before rolling down the windows.

### 3. Troubleshooting:

- Bubbles? Use a squeegee in smooth strokes to remove trapped air.
- Peeling edges? Ensure the glass was cleaned properly before application.
- Film not sticking? Check for dust particles and reapply solution.

For professional installation, consult an expert.