

Security & Safety Film Installation Guide

Security & Safety Film Installation Guide

1. Preparation:

- Clean the glass surface thoroughly.
- Measure and cut the film slightly larger than the window.
- Ensure a dust-free environment for installation.

2. Application:

- Wet the window with a soap and water solution.
- Remove the film backing and spray the adhesive side with solution.
- Position the film carefully and press it against the glass.
- Use a squeegee to remove excess water and air bubbles.
- Trim excess film along the edges.

3. Drying Time:

- Allow 72 hours for full adhesion.
- Avoid touching or cleaning the film surface during this period.

4. Additional Security Measures:

- Ensure proper edge sealing for maximum strength.
- Regularly inspect the film for signs of wear.

For high-security applications, professional installation is recommended.